


Technical Support

 01273 811011

 support@paxton.co.uk

Technical help is available: Monday - Friday from 07:00 - 19:00 (GMT)
Saturday from 09:00 - 13:00 (GMT)


Documentation on all Paxton products can be found on our website - <http://www.paxton.co.uk/>

RJ45 connector

During the manufacture of all Paxton products, units are checked on automated test equipment to ensure that they operate correctly. An RJ45 plug is fitted to speed up this process and this is now left attached to the cable after testing is completed.


The reader port module is designed to convert the standard reader ports on Switch2 and Net2 controllers to accept one or two RJ45 connections. Pull off the screw terminal block from the reader port and simply replace it with this module.

This will greatly speed up the installation and replacement of readers to the controller.



IMPORTANT: Ensure that only Paxton readers are connected to these RJ45 ports. Other equipment may be damaged if connected to these ports in error.

Technical Support

 01273 811011

 support@paxton.co.uk

Technical help is available: Monday - Friday from 07:00 - 19:00 (GMT)
Saturday from 09:00 - 13:00 (GMT)

Documentation on all Paxton products can be found on our website - <http://www.paxton.co.uk/>


RJ45 connector

During the manufacture of all Paxton products, units are checked on automated test equipment to ensure that they operate correctly. An RJ45 plug is fitted to speed up this process and this is now left attached to the cable after testing is completed.

The reader port module is designed to convert the standard reader ports on Switch2 and Net2 controllers to accept one or two RJ45 connections. Pull off the screw terminal block from the reader port and simply replace it with this module.

This will greatly speed up the installation and replacement of readers to the controller.

Remove Net2 reader cable plug and replace with this module.



IMPORTANT: Ensure that only Paxton readers are connected to these RJ45 ports. Other equipment may be damaged if connected to these ports in error.